

32-171-1602



mont-bell


Adjustable Fitting Pad

カヤックのフィッティングが簡単に調節できる着脱式のパッドです。シンプルな調整方法なので一つの艇を数人で利用する際に最適です。

カヤックへの装着方法

1. フィッティングパッドのテープをカヤックのシートサイドに回してください。


2. バックルでしっかり締め込んで動かないように固定します。この際、実際に艇に乗り込んで左右の位置や高さも調節してください。



フィッティングの調整方法

付属のフォームパッドを必要に応じて挿入し、最適なフィッティングが得られたら蓋をベルクロで固定してください。

蓋の裏にはドライバー等の工具を収納するのに便利なポケットを設けています。



⚠ 注意

過度のフィッティングは脱艇の妨げになり大変危険です。特に初心者の方はフィッティング調整の際にはスムーズに脱艇できることを確認しながらおこなってください。

32-171-1602



mont-bell


Adjustable Fitting Pad

This removable pad is designed to easily adjust to your kayak. This simple system is great for when multiple people need to use the same kayak.

Attaching to the kayak

1. Wrap the straps around the seat's sides.


2. Pull the straps and secure tightly with the buckles. When sitting in the kayak, adjust the pad's positioning laterally and vertically.



Adjusting the fit

Insert the included foam pads to adjust the fit. Close the lid and secure with Velcro.

The inside of the lid has a pocket for storing tools, such as a driver.



⚠ Caution

When adjusting fit, excessive padding can prevent exiting the kayak and is extremely dangerous. Especially for beginners, when adjusting the fit of the pad, make sure you are able to properly exit the kayak.