

■ 保管方法

- 本製品を長期間使用せずに保管する場合は、付属のケースに収納して直射日光または蛍光灯の当たらない風通しの良い場所に保管してください。
- 水着、タオルや他のものと長時間接触した状態で放置すると、ごくまれに色が移ることがあります。また、水に濡れたまま長時間放置しておく、くもり止め効果が落ちたり、カビが発生する場合がありますので、十分に陰干してから保管してください。
- 車の中や直射日光が当たる場所、暖房器具や火の近く、サウナなど高温になる所での乾燥・保管は、変色・変形や性能劣化の原因となる恐れがあります。

■ 廃棄方法

- 廃棄方法はお客様の自治体の収集方法に従ってください。

■ アフターサービス

お問い合わせいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お問い合わせいただいた販売店、もしくは下記の弊社窓口までご連絡ください。製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様・サイズ

品番：1127608
品名：スイミングゴーグル Kid's
素材：フレーム・レンズ：ポリカーボネート アイカップ・ストラップ：シリコーンゴム
ノーズブリッジ×3 (S・M・L)、ハードケース

付属品：

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

取扱説明書

スイミングゴーグル Kid's

Swimming Goggles Kid's


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

川や海での水遊びからスイミングスクールまで、さまざまなシーンで活躍する子ども用のスイミングゴーグルです。肌にやさしくソフトなシリコーンゴム製アイカップ、ストラップを使用し、快適にフィットします。くもり止め・UVカット加工を施し、クリアで快適な視界を確保します。軽量で耐衝撃性に優れたポリカーボネートレンズを使用しています。顔にあわせてS・M・Lの3サイズに交換可能なノーズブリッジ付き。

■ 各部の名称



保護者の方へ

- お子さまがご使用になる際は、保護者の方が本説明書をよくお読みになり、お子さまが理解できるようにご説明ください。
- お子さまが着用の際は、お子さまの顔にフィットし、正しくご使用されているかを保護者の方が必ず確認してください。
- 本製品は3歳以上を対象年齢としていますが、3歳以上でもサイズの合わない場合はご使用できません。

■ 安全上の注意 **必ずお読みください**

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本商品は水泳専用ゴーグルです。水泳以外（ダイビングなど）には絶対に使用しないでください。
- 水圧の影響で目が痛くなる場合がありますので、ダイビングのように深く潜らないでください。
- ゴーグルをつけた状態でレンズを顔から前方向に引っ張らないでください。また、着脱の際も取り扱いに十分注意してください。ストラップの伸縮により、レンズが跳ね返って顔や目をケガする恐れがあります。
- 体調に異常がある場合は使用しないでください。
- 薬品類（風邪薬）を服用して使用しないでください（薬を常用されている方は処方した医師に相談ください）。
- お子さま同士や、一人での遊泳は危険ですのでしないでください。

注意 人が傷害を負ったり物的損害の発生が想定される内容です。


- 快適にご使用いただくために、ストラップとノーズブリッジを顔にフィットするように調節してからご使用ください。調節が不十分な場合は水漏れの原因となったり、着用時に不快感が生じる場合があります。
- 長時間使用の際など、ごくまれに肌に異常があらわれる場合があります。その際はただちに使用を中止してください。万が一、アレルギー症状が出た場合には医師の診断を受けてください。
- ご使用前に必ず各部を点検してください。本体各部に亀裂・劣化・破損などがある場合は使用しないでください。
- お子さまがご使用になる際は、十分に使用方法を理解したかどうかを確認の上、必ず保護者の監視下でご使用ください。
- 本製品の改造・分解などは絶対に行わないでください。また、本製品には無理な力を加えないでください。変形したり破損する場合があります。
- 本製品は衝撃等によるケガ等から目を保護するための製品ではありません。水泳中や水に飛び込む際など着用中の衝突や接触には十分注意してください。
- ゴーグルのレンズは傷がつくと小さな衝撃でも破損する可能性があります。傷が見られる場合は使用を中止し、別のゴーグルを使用してください。
- 使用中の衝突や接触、ゴーグルの落下には十分注意してください。レンズが割れる場合があります。
- ゴーグル内に砂などが付着すると水漏れの原因となります。ご使用前に水洗いをして、砂利等をきれいに除去してください。
- シリコンゴム製品は、直射日光または蛍光灯による変色が起こる事がありますが、使用上は問題ありません。変色を避けるために、光の当たらないところに保管することをお薦めします。
- レンズ内側はくもり止めを施し、非常にデリケートです。使用の際は、直接指で触れないよう丁寧に取扱ってください。
- 日焼け止め、整髪剤等は、レンズやアイカップに付着すると落ちない場合がありますのでご注意ください。

■ 使用前の点検

- レンズ面に亀裂や欠けがないか
- ストラップ、アイカップ、フレーム、ノーズブリッジなどに傷や異常がないか

■ 使用方法

- **ゴーグルの着用方法**
レンズ保護のためのマスキングシールをはがしてからご使用ください。
 - ① あらかじめストラップの長さを調節します。
ストラップを両手で広げ、後頭部から着用し、レンズを額にのせます。
 - ② 左右のフレームを両手で持ちながら、目を覆うようにやさしく着用してください。
- **ゴーグルの取り外し方法**
 - ① 親指を頭の両脇のストラップの下に入れます。
 - ② 親指を後頭部までずらし、ストラップを後から前へゆっくり持ち上げ、外します。
※ストラップが切れる場合がありますので、調節の際は爪を立てないようにしてください。
- **ノーズブリッジの調節**
 - 3サイズ（S・M・L）のノーズブリッジが付属していますので、好みの長さをお選びください（出荷時はMサイズを取り付けています）。
 - ノーズブリッジは図のように、矢印方向にずらすようにして外します。取り付けの際は、奥までしっかりとめ込むように注意して取り付けください。



■ お手入れ方法 間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- レンズ内側に汚れや油脂分などが付着すると、くもりの原因となります。汚れが目立つ場合は市販の中性洗剤をうすめて入れた水で洗い、その後洗剤をよく洗い落としてください（シャンプー・リンスは使用しないでください）。洗剤が残っていると、プラスチック素材の変形、ひび割れ等が起こる場合があります。
- 砂が付いた際はこすらず、必ず水道水ですすぎ洗いしてください。
- 使用後は必ず水道水でよくすすぎ洗いをしてから、水気をよく切り、陰干ししてください。水分が付いたまま保管すると部材の劣化や変色、浸水や破損の原因となります。
- シンナーやアルコール等の有機系溶剤や洗剤の原液などを使用したり、洗剤などに長時間浸さないでください。変形・変色の原因となり、水中で製品が破損する恐れがあります。付着した場合はすぐに真水で洗い流してください。

■ Disposal

Please follow local regulations regarding waste disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Style# : 1127608

Name : Swimming Goggles Kid's

Material : Frame / Lens : Polycarbonate

Gasket / Strap : Silicon

Includes : Nose bridge x 3 (S, M, L)

Hard case

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com

4

44-3406-1806

mont-bell

User's Manual

Swimming Goggles Kid's

Swimming Goggles Kid's


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Description

These kid's goggles offer a clear vision at swimming pools, rivers and beach. Soft silicon gasket and strap offer excellent fitting. The polycarbonate lens is lightweight and impact durable, prevents lens from fogging, and protects eyes from harmful UV rays. Includes 3 interchangeable nose bridge (S, M, L).

■ Components



Note to parents/guardians

- Prior to use, parents/guardians should thoroughly read this manual and ensure that the child understands proper use of the product.
- Prior to use, ensure that the mask is properly fitted to the child's face.
- This product is designed for children age 3 years and above. However, may NOT be suitable depending on child.

■ Safety Warnings! Please read carefully.

⚠ WARNINGS! Under certain conditions, use of this product can result in injury, death, or property damage.

- This product was designed for swimming. Do NOT use this product for any other activity (diving) for which it was not designed.
- Do NOT use for diving. Water pressure may cause eye injuries.
- Do NOT pull on the lens while wearing this product. Be careful when removing. The strap may stretch back and cause injuries.
- Do NOT use this product if feeling uncomfortable or sick.
- Do NOT use this product in conjunction with medication such as cold medicine. (Prior to use, consult with your physician if currently taking medication.)
- Do NOT swim by yourself or allow children to swim unsupervised.

⚠ CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- Prior to use, adjust the strap and nose bridge. Improper adjustment may cause water leakage and discomfort during use.
- If you experience a rash, itching, or swelling on the skin, stop using immediately and consult a physician.
- Prior to use, always inspect all components. Do NOT use this product if there are cracks, deterioration, or damage.
- Prior to use, parents/guardians should thoroughly read this manual and ensure that the child understands proper use of this product.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- This product is NOT designed to protect your eyes from impacts. Make sure your surroundings when swimming to avoid collisions.
- Stop using immediately if you notice any damage or irregularities on the lens.
- To prevent lens damage, do NOT apply strong impacts or drop this product.
- Prior to use, always wash soiling and sand. Improper care may cause water leakage.
- Silicone rubber products may discolor when exposed to direct sunlight or lighting. However, this does NOT affect the performance. To avoid discoloration, store the product away from lighting.
- Do NOT touch the inner lens. May damage and decrease the anti-fogging performance.
- Do NOT put sun screen or hair gel on the lens or gasket. May cause stains and impair functions.

■ Prior to use, inspect this product for:

- Cracks and damage on the lens
- Damage and irregularities on the strap, gasket, frame and nose bridge

■ Directions

○ Wearing the goggles

Prior to use, remove the attached lens-protection sticker.

- ① Prior to use, adjust the strap length using both hands. Wear it from the back of the head and place the lens on the forehead.
- ② Hold the frame with both hands and gently place it over your eyes.


○ Removing the goggles

- ① Place your thumb under both sides of the strap.
- ② Move your thumb towards the back of the strap. Lift the strap and gradually shift your thumb forward.

*Be careful not to tear the strap with your finger nails.

○ Adjusting the nose bridge

- Choose from 3 interchangeable nose bridge (S, M, L). Size M is attached as a standard.
- To remove the nose bridge, pull in the direction as shown in the picture. Make sure to securely attach the nose bridge when replacing.



■ Care

Improper care and storage can shorten the lifespan of this product. Follow the recommendations below to extend the lifespan of your product.

- Soiling and oil stains may damage the inner lens, decreasing the anti-fogging performance. Remove stains using mild soap and rinse thoroughly for preventing material deterioration (Do NOT use shampoo or conditioners).
- Always wash soiling and sand with water.
- Always wash with water after use. Avoid direct sunlight and allow to air-dry in a cool, well ventilated area. If stored wet or soiled, the materials can start to prematurely deteriorate.
- Do NOT clean this product with paint thinner and alcohol. Do NOT soak the product for long periods of time in detergent or other cleansers. This may cause deformation and discoloration, as well as breakage of the product while submerged. Immediately rinse any residue with fresh water.

■ Storage

- Store inside the hard case in a well ventilated, cool, dry place away from direct sunlight.
- Do NOT leave this product unattended for long periods alongside wet bathing suits and towels. May cause color stains, decrease anti-fogging performance, and mold can grow. Always store the product after thoroughly drying.
- Do NOT store or dry this product under direct sunlight or near heat sources. May cause discoloration, deformation, and lead to decrease in performance.