

mont·bell

取扱説明書

レインブーツ Kid's/Baby's

Rain Boots Kid's/Baby's

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は雨の日のお出かけや、通園・通学にご使用頂ける子ども用の軽量な長靴です。フットベッド(中敷き)が取り出せるので、乾かしやすく、お手入れも簡単です。

■ 安全上の注意 必ずお読みください

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- オイル等が靴底に付着すると滑る危険性があります。
- 発汗などによるかゆみ、かぶれが生じた際は、直ちにご使用をやめ、医師に相談してください。また、履き口との擦れにより、靴擦れを起こすことがあります。その場合は、長ズボンや靴下の着用をお勧めします。
- 高温になる場所に放置しないでください。破損の恐れがあります。
- エスカレーターをご利用の際は、お子さまが誤ってステップに靴が挟み込まれないよう保護者の方が手をつないでお乗りください。
- 釘など鋭利なものの突き刺さりにご注意ください。ケガの恐れがあります。
- 低温(約-20度)の状況下でのご使用はお避けください。素材の特性により硬化するため、歩きづらくなったり滑る恐れがあります。
- 異常が見受けられた場合は直ちに使用をやめ、販売店または弊社カスタマー・サービスまでお問い合わせください。
- 濡れたまま放置しないでください。色が他の物に移ることがあります。

■ 使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。

- 靴本体やアウトソール(靴底)、ミッドソール(中底)に異常がないか
- 屈曲を繰り返してアウトソール(靴底)にひび割れ等の異常がないか

■ お手入れ方法 間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

○汚れ落とし

1)フットベッド(中敷き)・靴内部

フットベッド(中敷き)は使用するたびに取り出し、しっかり乾燥させてください。また、取り出すことで靴内部も乾かしやすくなります。また、汚れがひどい時は中性洗剤とブラシで洗ってください。靴内部のライニングはブラッシングで汚れをかき出してください。

2)アッパー(甲)部分

頑固な汚れは水洗いしてください。

3)アウトソール(靴底)

水洗いしてください。

○乾燥

直射日光を避けて、風通しの良いところで2~3日かけて乾燥させてください。

■ 保管方法

○本製品を長期間使用せずに保管する場合は、風通しが良く、湿度が高くない場所で、直射日光を避けて保管してください。

○折り曲げて保管しないでください。

※以下のような場所には保管しないでください。機能が低下する恐れがあります。

- ・購入時の靴箱や収納袋
- ・直射日光のあたる庭の物置
- ・車のトランクなど高温になる場所

■ 廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont·bell

User's Manual

Rain Boots Kid's / Baby's

Rain Boots Kid's / Baby's

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Features

These lightweight rubber boots are well suited for rainy day outings, on the way to school or playing outside. With a removable insole, these boots dry quicker and are easier to care for.

■ Warnings!

Please read carefully.

 **Caution!** Under certain conditions, use of this product can result in injury or property damage.

- Certain substances, such as oil, can cause slipping.
- If itching or rash develops, stop using these boots immediately and seek medical attention. In case the top edge of the boots rubs against your calf and causes blisters, we recommend to wear long trousers or socks.
- Do not store in areas subject to high temperatures. Heat can damage boots.
- When riding an escalator, please hold your child's hand and be careful of accidental catching in the steps of the escalator.
- Be careful of sharp objects, such as nails, as they can penetrate these boots and cause injury.
- Do not use when temperatures are below -20 degrees Celsius (-4 degrees Fahrenheit). Boots may harden at this temperature making it difficult to walk and increase your child's chance of tripping.
- If you notice any abnormalities with your boots, stop using and contact Montbell Customer Service or the store of original purchase.
- Do not allow shoes to sit while wet. Wet shoes can transfer color to other objects.

■ Check before use

Check your boots before each use for irregularities and wear and tear. If unfit for use, do not wear.

- Check for irregularities with the outsole and midsole.
- Bend the sole to check the sole for cracks and other irregularities.

■ Care and Maintenance

Improper care and storage of your boots can shorten their lifespan. Follow the recommendations below to extend the lifespan of your boots.

○ Cleaning

1) Insole and inside the shoe

After using, remove the insole and allow to air dry. Removing the insole allows the inside of the boot to dry quicker. In cases of heavy soiling, use a mild detergent with brush.

Brush the lining to remove dirt.

2) Upper

Use a shoe brush to remove dirt and water to remove heavy soiling.

3) Outsole

Wash with water.

○ Drying

Avoid direct sunlight and allow to air dry in a cool well ventilated area.

■ Storage

- Store in a well ventilated, cool, dry place. Storing boots in the following locations can damage your boots:
 - The original box or bag at the time of purchase.
 - Any area that receives exposure from direct sunlight.
 - A car trunk or other area subject to high temperatures.
- Do not allow shoes to bend or fold during storage.

■ Disposal

- Follow local rules and regulations for proper disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear.

Damage(s) not covered under warranty will be repaired at a reasonable rate.

If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont·bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com

44-1691-1905