

■ 保管方法

- 火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。
- 保管場所は直射日光の当たらない風通しの良い場所を選んでください。

■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

■ 仕様

品番：1129619

品名：スノースパイク6

爪の長さ：最大23mm

素材：アイゼン本体(S55C鋼 板厚2.0mm)、バンド(ナイロン)

対応靴サイズ：フリーサイズ(21.5~30.0cm)

※靴の形状によっては対応サイズでも装着できない場合があります。

※フラットソールの靴には対応しません。

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

取扱説明書

スノースパイク 6

SNOW SPIKE 6

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。


ただし、本説明書は本製品の基本的な使用方法を示すものであり登山の安全システムを解説するものではありません。安全な条件のもとで十分な練習を行い、正しい使用方法を習得してください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

本製品は十分な強度と快適な装着感を持ち、雪がダンゴ状に付着しにくいアンチスノープレートを装備した軽アイゼンです。夏の雪渓や、冬の低山歩行用として最適です。

■ 各部の名称



■ 安全上の注意 必ずお読みください

危険 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

- 登山は常に潜在的な危険をはらんでいます。たとえ用具の正しい選択、使用、お手入れ、保管を行なっても傷害や死亡事故などに至る危険性を完全に排除することは出来ません。個人の責任において登山を行ってください。(株)モンベルでは本製品の誤った使用に起因する損害や傷害、死亡事故に対していかなる責任をも負いません。

- 本製品は簡易アイゼンです。本格的な雪山登山には使用しないでください。
- 本製品は登山専用のアイゼンです。その他の用途には使用しないでください。

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。
軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品に対応する靴のサイズでご使用ください。対応サイズ外の場合は本来の性能が発揮できない恐れがあります。
- 使用方法をご覧のうえ、靴に合わせてサイズを正しく調節してください。正しく調節しないと本来の性能が発揮できない恐れがあります。
- フラットソールの靴には合いません。土踏まず部が凹状、かかと部が凸状になっているかを確認してからご使用ください。
- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に保護能力が発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合には直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。
- アイゼンの底についた雪や雪の固まりは常に取り除いてください。放置すると爪が効かず、本来の制動力を発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- 携行する際は左右のアイゼンの爪を内側に重ね、付属の収納袋に入れてください。
- アイゼンを使用する際は十分に歩行練習などを行ってください。アイゼンを装着していないときに比べ爪を引っ掛けて転倒する可能性が高くなります。
- 本製品は氷雪上の滑り止め用具です。氷雪以外で使用すると爪が折れ曲がったり、アンチスノープレートが傷ついたり破損することがあります。

■ 使用前の点検 使用にあたっては、毎回必ず次のことを確かめてください。

- 爪やアンチスノープレートやチェーンにひびや変形が見られないか
- テープにほつれなどがいないか
- バックルは正しく機能するか

■ 使用方法

本製品の性能を十分に発揮させるために、使用者の靴にしっかり合うようにサイズ調節を行ってください。不適切なサイズ調節や、装着ではアイゼンが靴から外れたりして危険です。サイズ調節は必ずフィールドに行く前に行ってください。

○ **対応靴サイズ** フリーサイズ (21.5~30.0cm) ※靴の形状によっては対応サイズでも装着できない場合があります。


○ **装着方法**
※図は右足です。
※取り外す際は、装着方法と逆の順序で取り外してください。

本製品は左右があります。


- 1 装着するときは靴底の雪や土を、よく取り除いてください。
- 2 アイゼンをバックルの付いている方が外側になるよう地面(雪面)に置きます。(図a)




3 アイゼンの2箇所の突起が靴の土踏まずに合うようにします。後部テープを靴のかかと部へ回し、かかと部のチェーンが垂直になるように後部テープの長さを調節します。この際、後部テープがミッドソールの上部を通っていることを確認してください。(図b)



4 前部テープを(図c、図d)の順番でリングに通してください。




5 バックルに前部テープを(図f)のように通し、アイゼンの前部テープと後部テープが靴に密着するようにテープを調節し、(図g)のようにテープをバックルに通して締めます。



※フィールドで使用する前に説明書なしで手早く着脱できるよう練習してください。
※テープは部分的に緩んだりせず、左右対称で均等に締まっているかを確認してください。

○ **テープの長さ調節**

テープの長さはバックルから約6~7cm出るように切ってください。切断面をライターなどで溶かして固めてください。



■ お手入れ方法 間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- ご使用後は水洗いをして泥などを落とし、乾燥させて、金属部分に市販の防錆油等を塗布してください。
- テープやバックルなどにキズや破損等がないかを確認してください。
- アイゼンの爪が摩耗しているときは金ヤスリ等で削ってください。

■ **Care** Improper care and storage can shorten the lifespan of this product. Follow the recommendations below to extend the lifespan of your product.

- Wash away stains and soiling with water. Avoid direct sunlight and allow to air dry in a cool well ventilated area before applying a corrosion inhibitor.
- Check for damage to the straps and buckles.
- When points have become worn, use a file to sharpen.

■ Storage

- To prevent deforming and damage to the product, do not store near heat sources.
- When storing for an extended period of time, store in a well ventilated, cool, dry place out of direct sunlight.

■ Disposal

- Please follow local regulations regarding waste disposal.

■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at our discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

■ Specifications

Style #: 1129619
Name: Snow Spike 6
Point length: 23mm max
Materials: (Crampon) carbon steel (2.0mm thick), (Strap) nylon
Shoe size compatibility
One size fits most (21.5 - 30cm)
*Shoes may not fit due to shape, even if within size range.
*These micro crampons are NOT compatible with flat soled shoes.

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com

4

44-2505-1802

mont-bell

User's Manual

Snow Spike 6

Snow Spike 6

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


However, the information in this User's Manual only covers the basic use of these crampons and does not cover outdoor safety. We recommend practicing the use of these crampons under safe and controlled conditions.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

■ Description

These micro crampons have excellent strength and durability, combined with an anti-snow plate that prevents the buildup of snow on the underside of the crampon. They are easy to use when hiking in summer on remaining snow or during light winter trekking.

■ Features



■ Safety Warnings! Please read carefully.

⚠ DANGER! Under certain conditions, use of this product can result in major injury or death.

- Mountaineering and rock climbing are inherently dangerous activities. Even if these crampons are used, cared for, and stored correctly, it will not completely eliminate the risk of major injury or death. You are responsible for your own actions and decisions. Montbell Co. LTD is not liable for damages or accidents resulting in injury or death resulting from improper usage.
- This product is a micro crampon. It is NOT designed for use in alpine conditions.
- These micro crampons are NOT designed for any other purpose other than trekking and hiking.

WARNING! Under certain conditions, use of this product can result in injury, death, or property damage.

- Make sure this product is correctly sized to match your shoes. This product will not perform as intended if not correctly adjusted.
- Follow the instructions for adjusting fit to your shoes. This product will not perform as intended if not correctly adjusted.
- These micro crampons are NOT compatible with flat soled shoes. Check to make sure your shoe has an concaved arch and the heel is prominent.
- Do not modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Routinely clear snow from the crampons. Accumulated snow can prevent the crampon's points from performing as intended.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.

CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- For transporting, use the included stuff sack and stack the crampons so the points face each other.
- Please practice walking while wearing crampons. The crampon's points can make it difficult to walk, increasing the chances of tripping or falling.
- This crampon is meant for use on ice and snow. The points can bend or break and the anti-snow plates can become damaged when used on surfaces without ice or snow.

■ Prior to use, inspect this product for:

- Damage or deforming on the points or anti-snow plates.
- If the strap is frayed or torn.
- If the buckle is working properly.

■ Directions


In order for these crampons to perform as intended, they must be correctly sized to your shoes. If not properly sized or attached to the shoes, there is a possibility the crampons can become loose and separate from your shoes during use. Perform sizing and fitting adjustments before use.

- **Shoe size compatibility** One size fits most (21.5 - 30cm)
*Shoes may not fit due to shape, even if within size range.


- **Putting on**
*Illustration shows right shoe.
*To take crampons off, follow the procedures below in reverse.

Match crampons to left and right shoes.


- 1 Before putting on, clear off any snow or dirt on the bottom of the sole.
- 2 Make sure the crampon's buckle is positioned on the outer side of the shoe (see Fig. a).




- 3 Make sure the crampon's two ridges are under the shoe's arch. Wrap the heel strap around the heel of the shoe. Adjust the length of the heel strap so the chain rises straight up. Make sure the heel strap is placed right above the shoe's midsole (see Fig. b).



- 4 Wrap the strap over the instep and loop it through the two rings in the following order (see Fig. c then Fig. d).



- 5 Wrap the strap over the instep and loop it through the buckle (see Fig. f). Adjust the tightness of the strap so that the heel strap and instep strap have good contact with the shoe. Lastly, loop the strap through the top of the buckle (see Fig. g).



*Practice before hand so that you are able to take off and put on the crampons without this manual.
*Check for slack in both the left and right straps and make sure they are secured.

- **Adjust tape length**

Cut excess strap leaving 6 to 7cm.
Use a lighter or other heat source to melt the ends.

