

# mont-bell Kajitax

## 取扱説明書

# アンチスノープレート LX-10用

### Anti Snow Plate For LX-10

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は、カジタックスアイゼン LXT-10シリーズ専用の交換用アンチスノープレートです。※2016年以前のモデルには対応しません。※本製品はアイゼンの別売オプションです。単体では使用できません。

## ■ 安全上の注意 必ずお読みください

※アイゼン本体の取扱説明書に記載の注意事項を必ずお読みください。

**危険** 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

○登山、クライミングは常に潜在的な危険をはらんでいます。たとえ用具の正しい選択、使用、お手入れ、保管を行なっても傷害や死亡事故などに至る危険性を完全に排除することは出来ません。個人の責任において登山、クライミングを行ってください。(株)モンベルでは本製品の誤った使用に起因する損害や傷害、死亡事故に対していかなる責任を負いません。

○本製品は登山、クライミング専用です。その他の用途には使用しないでください。

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

○対応するアイゼンに使用してください。

○本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に保護能力が発揮できない恐れがあります。

○使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合には直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。

○正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

○本品は氷雪上用です。氷雪上以外で使用するとアンチスノープレートが傷ついたり破損することがあります。

## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。


□ひびや変形や摩耗が見られないか

## ■ 取り付け方法

※本製品は左右があります。本製品は消耗品です。傷ついたら早めに交換してください。

### ジョイントバーを外す

① プルタブを持ち上げて、サイズ調節ピンのロックを解除し(図A)、ジョイントバーを引き抜きます(図B)。



## ■ 各部の名称

※写真のカジタックス LXT-10 アイゼンは付属しません。




## 古いアンチスノープレートを外す

※イラストは底側から見た図です。



## 新しいアンチスノープレートを取り付ける

※イラストは底側から見た図です。



## ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

○ご使用後は水洗いをして泥などを落とし、乾燥させてください。

## ■ 保管方法

○直射日光の当たらない風通しの良い場所を選んでください。

○本製品を火のそばや暖房器具のそばなどの高温になる所に置かないでください。変形や損傷の原因になります。

## ■ 廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■ 仕様

品番: #1141158 対応アイゼンサイズ: S/M/M/L(各サイズ共通)  
品名: アンチスノープレート LX-10用 ※左右一足分セット 対応カジタックスアイゼン: #1141147 LXT-10  
#1141148 LXT-10ワイド

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# Anti Snow Plate For LX-10

## Anti Snow Plate For LX-10


Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

### Description

For the LXT-10 models. For replacing damaged or worn snow plates on your Kajitax crampons. \*Not compatible with models made before 2016. \*This product must be used with the Kajitax Eisen crampons and cannot be used independently.

### Components

\*Does NOT include the LXT-10 Kajitax Eisen crampons.



### Safety Warnings!

Please read carefully.

**DANGER!** Under certain conditions, use of this product can result in major injury or death.

- Mountaineering and climbing are inherently dangerous activities. Even if this product is used, cared for, and stored correctly, it will not completely eliminate the risk of major injury or death. You are responsible for your own actions and decisions. Montbell Co., Ltd. is not liable for damages or accidents resulting in injury or death resulting from improper usage.
- This product is made for winter mountaineering and climbing. Do NOT use this product for any other activity for which it is not designed.

**WARNINGS!** Under certain conditions, use of this product can result in injury, death, or property damage.

- Make sure to attach this product to compatible Kajitax Eisen crampons.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Prior to use, check the product's condition and stop using immediately if you notice any deterioration from age/use, damage or irregularities.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.

**CAUTION!** Under certain conditions, use of this product can result in injury or property damage.

- This product is meant for use on ice and snow. The anti snow plates can become damaged when used on surfaces without ice or snow.

### Prior to use, inspect this product for:


- Damage or deformation on the anti snow plates

**Directions** This product has a left and right. The anti snow plates will gradually weaken from normal use and age. Replace the plates when damaged.

#### Removing the linking bar

- 1 Pull the adjustment clip to release the pin from the linking bar (see Fig. A).

\*If the linking bar drops out, insert the bar from the opening of the anti snow plate (see Fig. B).




### Removing the old Anti Snow Plates

\*Rear view of the crampons.

#### Front plate

- 1 Lift the front plate from the attachment bar located in the back-end.
- 2 Remove the front plate in the direction of the arrow.



#### Back plate

- 1 Lift the back plate by slightly bending from the attachment bars.
- 2 Remove the back plate in the direction of the arrow.




### Attaching the new Anti Snow Plates

\*Rear view of the crampons.

#### Front plate


- 1 Insert the front plate in the direction of the arrow. \*Make sure the side with the Montbell logo faces toward your feet.
- 2 Slightly bend the front plate and securely attach it to the attachment bar located in the back.



The dented edge of the Anti Snow Plate

#### Back plate

- 1 Insert the back plate in the direction of the arrow. \*Make sure the raised back-end faces toward the ground.
- 2 Slightly bend the back plate and securely attach it to the 2 attachment bars.



The dented edge of the Anti Snow Plate

### Care

Improper care and storage can shorten the lifespan of this product. Follow the recommendations below to extend the lifespan of your product.

- Wash away stains and soiling with water. Avoid direct sunlight and allow to air dry in a cool well ventilated area before applying a corrosion inhibitor.

### Storage

- To prevent deforming and damage, do NOT store near heat sources.
- When storing for an extended period of time, store in a well ventilated, cool, dry place out of direct sunlight.

### Disposal

- Please follow local regulations regarding waste disposal.

### Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

### Specifications

Style# : #1141158

Name : Anti Snow Plate For LX-10 \*Sold in a pair

Compatible sizes: S/M, M/L (compatible to all sizes)

Compatible Kajitax Eisen crampons: #1141147 LXT-10, #1141148 LXT-10 Wide

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com