


32-439-1507



mont-bell

### Light Photo Shoulder Bag

コンパクトに折り畳め、バックパックの中などに入れてインナーバッグとして携行することができるカメラバッグです。



- A 取外し可能なショルダーストラップ
- B ハンドル
- C 振れを防止するウエストベルト (収納式)
- D 小物の収納に最適なジッパーつきポケット

<b>XS サイズ</b> (収納例:ミラーレス一眼+標準レンズなど)
高さ12.0× 幅17.0× 奥行き9.0cm
<b>S サイズ</b> (収納例:小型一眼レフ+標準レンズなど)
高さ18.0× 幅22.0× 奥行き12.0cm
<b>M サイズ</b> (収納例:小型一眼レフ+広角～標準レンズなど)
高さ20.0× 幅28.0× 奥行き12.0cm
<b>L サイズ</b> (収納例:中型一眼レフ+望遠レンズなど)
高さ22.0× 幅32.0× 奥行き15.0cm

※収納例はカメラ等収納物の形状により異なります。

- 全面に軽量のフォームを封入
- 機材を雪やホコリから保護するパウダースカート


32-439-1507



mont-bell

### Light Photo Shoulder Bag

This camera bag is perfect for travel since it folds up compactly making it convenient to bring with you while traveling in your backpack or use as an inner bag in your suitcase.



- A Detachable shoulder strap
- B Handle
- C "Stow-away" hipbelt
- D Front zippered pocket

<b>XS Size</b> (Can hold a mirrorless camera and a standard lens)	12× 17× 9cm
<b>S Size</b> (Can hold a smaller sized SLR camera and a standard lens)	18× 22× 12cm
<b>M Size</b> (Can hold a small sized SLR camera and a wide angle or standard lens)	20× 28× 12cm
<b>L Size</b> (Can hold a medium sized SLR camera and a telephoto lens)	22× 32× 15cm

※Actual bag capacity is depends on camera size and other items.

- Lightweight foam padding
- Powder skirt