

mont·bell

共通取扱説明書

サワーサンダル シリーズ

Sawer Sandals Series

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

お持ちの沢登り用の靴に装着できるサンダルです。シーンに合わせて最適なグリップ力を得ることが可能。また、独自の取り付け構造により、高いフィット感を実現しています。

■ 各部の名称

サワーサンダル フェルト

サワーサンダル ラバー

サワーサンダル フェルト タビ用



■ 安全上の注意

必ずお読みください

警告 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- 本製品の改造や分解などは絶対にしないでください。性能が損なわれ、十分に機能が発揮できない恐れがあります。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。
- 使用前は毎回必ず点検をしてください。老朽化が認められる場合や損傷が認められたり、疑わしい場合は直ちに本製品の使用を中止してください。本来の性能が発揮できない恐れがあります。

1

注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- アウトソール（靴底）の貼りつけに使用している接着剤は、使用の有無にかかわらず経年劣化により剥離が起こる可能性があります。使用後のお手入れや保管方法は本説明書に従って行ってください。
- 経年劣化や接着剥離は使用中に突発的に起こる可能性が高く、事故の原因にもなる可能性があります。ご使用前はアウトソール（靴底）等に異常がないことを点検してください。
- アウトソール（靴底）は屈曲を繰り返してひび割れ等の異常がないか確認してください。異常が見受けられた場合は直ちに使用をやめ、販売店もしくは弊社カスタマー・サービスまでお問い合わせください。
- 油がひいてある場所で使用しないでください。転倒やケガの恐れがあります。
- アウトソール（靴底）の種類によって特性が異なります。右の表を参考にして、各ソールの特性を十分理解した上で使用してください。

グリップ力の目安

アウトソールの素材	滑りにくい ← → 滑りやすい		
	コケ	岩	草付
ポリプロピレンフェルト	○	○	△
ラバー（アクアグリップパー）	△	◎	○

■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。


- アウトソール（靴底）のはがれがないか
- 縫い目のほつれや留め具の脱落がないか
- アウトソール（靴底）が擦り減っていないか
- テープが傷んでいないか
- バックルに破損などがないか
- アウトソール（靴底）が屈曲を繰り返してひび割れ等の異常がないか（サワーサンダル ラバーのみ）

■ 使用方法


○ 装着方法

本製品は左右があります。アウトソール（靴底）のふくらみが外側になるよう装着してください。また、取り外す際は装着方法と逆の順序で取り外してください。

※フィールドで使用する前に説明書なしで着脱できるよう練習してください。
※テープは部分的に緩んだりせず、均等に締まっているかを確認してください。




サワーサンダル フェルト、サワーサンダル ラバーの場合 ※図は右足です。




1 本製品とお持ちのブーツのかかとをイラストのようにしっかりと合わせます。テープBにたるみがないように注意してください。




2 テープAの先端部分を、図のようにブーツのつま先にはめます。ブーツを固定するためにバックルを前後に動かし、つま先の形状に合うよう調整してください。







2



③左右のテープAを図のようにテープBの内側から通します。




④左右のテープAをブーツの甲で交差させ、図のようにテープBの内側から通します。




⑤左右のテープAの先端同士を、図のようにバックルで固定します。この時余ったテープが長い場合はハサミで斜めにカットした後ほつれないようにライターなどで末端を溶かしてください。
※テープをカットする場合はバックルから10cm以上残るようにしてください。


サワーサンダル タビ用の場合 ※図は右足です。




①本製品とお持ちのブーツのかかとをイラストのようにしっかりと合わせます。テープBにたるみがないように注意してください。







②イラストのように、タビのつま先の先割れ部分にテープAを通します。



③左右のテープAを図のようにテープBの内側から通します。



④左右のテープAをブーツの甲で交差させ、図のようにテープBの内側から通します。



⑤左右のテープAの先端同士を、図のようにバックルで固定します。この時余ったテープが長い場合はハサミで斜めにカットした後ほつれないようにライターなどで末端を溶かしてください。
※テープをカットする場合はバックルから10cm以上残るようにしてください。

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

汚れを放置すると経年劣化が進み、アウトソール(靴底)のはがれの原因につながります。

○ ご使用後のお手入れ

水洗いして、汚れを十分に落とした後、直射日光を避けて、風通しの良いところで2~3日かけて乾燥させてください。

※濡れた状態で直射日光やヒータ等で急激に乾燥させないでください。アウトソール(靴底)のはがれにつながる恐れがあります。

※本製品はアウトソール(靴底)の張り替えができません。

■ 保管方法

○風通しがよく、湿度が高くない場所で、直射日光を避けて保管してください。

○火のそばや暖房器具のそばなどの高温になるところに置かないでください。変形や損傷の原因になります。

○直射日光のあたる庭の物置や車のトランクなど高温になる場所に保管しないでください。変形や損傷の原因になります。

■ 廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理をさせていただきます。

■ 仕様

品番	1125119	1125120	1125121
品名	サワーサンダル フェルト	サワーサンダル フェルト タビ用	サワーサンダル ラバー
素材	(ソール) ポリプロピレンフェルト (テープ) ポリエステル	(ソール) ポリプロピレンフェルト (テープ) ポリエステル	(ソール) ゴム底 (テープ) ポリエステル

■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

mont-bell

User's Manual

Sawer Sandals Series

Sawer Sandals Series

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

These sandals can be used with the shower climbing shoes that you already own. Choose the type of sandals based on the conditions you are expecting. How to route the webbing is carefully designed so that the sandals are well secured to your shoes.

Components

Sawer Sandals Felt

Sawer Sandals Rubber

Sawer Sandals Felt Tabi



Safety Warnings! Please read carefully.

! WARNINGS! Under certain conditions, use of this product can result in injury, death, or property damage.

- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair function.
- Please follow recommended care and storage instructions. Improper care and storage can lead to decrease in performance.
- Prior to use, check the shoe's condition and stop using immediately if you notice any damage or irregularities.

! CAUTION! Under certain conditions, use of this product can result in injury or property damage.

- The adhesive used on the outsole will degrade over time, with or without regular use. To help prevent this, please follow the care and storage instructions in this manual.
- Accidents can occur while you are hiking or trekking due to adhesive failure or deterioration over time. Check for irregularities in the outsole before using.
- When inspecting the outsole, look for cracks in the rubber resulted from the repeated bending of the shoe. If you notice any damage or irregularities, stop using immediately and contact Montbell Customer Service or the original store of purchase.
- Do NOT use on oiled surfaces. It may cause slipping and injury.
- Refer to the table on the right for the characteristics of sole materials.

Gripping strength	← Grips → Slips →		
	Moss	Stone	Grass
Outsole material	○	○	△
Polypropylene Felt	○	○	△
Rubber (Aqua Gripper)	△	◎	○

Prior to use, inspect this product for:


- Outsole is peeling
- Worn-out outsole
- Damage to the stitching or missing buckles
- Webbing is damaged
- Buckles are damaged
- Cracks in the outsole from repeated bending (Sawer Sandal Rubber only)

Directions

○ Putting on

This product has a left and a right. Make sure that the outsole lines up with the shape of your shower climbing shoe. When taking off the Sawer Sandals, follow the directions below in reverse.

Right shoe




- Sawer Sandal Felt
- Sawer Sandal Rubber
- Sawer Sandal Felt Tabi


*Practice beforehand so that you are able to take off and put on the Sawer Sandal without this manual.

*Make sure that the webbing is evenly tensioned and there is no slack in it.


Sawer Sandal Felt / Sawer Sandal Rubber ※Figures below show right shoe.




① Line up the heel of your shower climbing shoe and the Sawer Sandal. Make sure that there is no slack in the webbing B.





② Wrap the webbing A over the toe. In order to make sure the shoe is secure in the Sawer Sandal, adjust the position of the buckle over the toe.




③ Take the webbing A and loop it through the inside of webbing B.




④ Cross the webbing A over the shoes on both sides and loop it once again through the inside of webbing B.




⑤ Take the ends of the webbing and loop the free end through the rings as shown in the fig. to secure. If the free end of the webbing is too long, cut it at an angle and use a heat source to melt the ends and prevent fraying. *When cutting the webbing, make sure to leave at least 10cm from the buckle.




Sawer Sandal Felt Tabi ※Figures below show right shoe.





① Line up the heel of your shower climbing shoe and the Sawer Sandal. Make sure that there is no slack in the webbing B.





② On tabi, make sure that the webbing A is seated between the toes.



③ Take the webbing A and loop it through the inside of webbing B.



④ Cross the webbing A over the shoes on both sides and loop it once again through the inside of webbing B.



⑤ Take the ends of the webbing and loop the free end through the rings as shown in the fig. to secure. If the free end of the webbing is too long, cut it at an angle and use a heat source to melt the ends and prevent fraying. *When cutting the webbing, make sure to leave at least 10cm from the buckle.

③

Care Improper care and storage can shorten the lifespan of this product. Follow the recommendations below to extend the lifespan of your product.

Leaving shoes soiled will make the shoes age quicker and can lead to faster deterioration of the outsole.

Care after use

Wash with water. Afterwards, allow to dry for 2 to 3 days out of direct sunlight in a cool, dry place.

*Do NOT dry wet shoes in the sun or near a heater or dryer. This can lead to faster deterioration of the outsole.

*The outsole of this product CANNOT be repaired.

Storage

○ Store in a well ventilated, cool, dry place. Storing in the following places can cause these shoes to deteriorate quickly.

○ Any area exposed to direct sunlight.

○ A car trunk or other area subject to high temperatures.

Disposal

○ Please follow local regulations regarding waste disposal.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate.

If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Specifications

Style#	: #1125119	#1125120	#1125121
Name	: Sawer Sandals Felt	Sawer Sandals Felt Tabi	Sawer Sandals Rubber
Material	: (Outsole) Polypropylene Felt (Strap) Polyester	(Outsole) Polypropylene Felt (Strap) Polyester	(Outsole) Rubber (Strap) Polyester

Others

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

<https://www.montbell.com/>

4

44-3664-2103