

取扱説明書

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書(以下「本説明書」といいます)は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

■ 特長

荷物をスムーズに運ぶことのできるキャスターつきの軽量なトラベルバッグです。独自のハンドル構造により、フラットな内部空間で無駄なく荷物を収納できます。

■ 各部の名称 / 機能説明



※写真はウィーリーダッフル 80です。

① キャリーハンドル

独自構造の薄型ハンドルにより、フラットな内部空間を実現しています。

② 手提げバッグ用ホルダー

手提げバッグなどを留めるストラップ。また、キャリーハンドルを使用しないときは、ストラップで固定することができます。

③ 鍵対応ジッパー

(メインジッパーのみ)
「TSAロック」(別売)などの鍵で施錠できるジッパーを使用しています。



④ コンプレッションベルト

荷物の量に合わせてコンプレッションベルトを絞ることで、荷物が動かず安定させることができます。

⑤ 荷物の出し入れがしやすいメインジッパー

張りがあるメインジッパーを使用することで、荷物の出し入れがしやすくなっています。

⑥ 荷物を認識しやすいメインコンパートメント

中に入れた荷物が確認しやすい明るい色の裏地を使用しています。

⑦ キャスター

直径が大きく安定性に優れたキャスターです。
※すり減った場合も交換・修理が可能です

⑧ キックプレート

バッグを保護するとともに、歩き出す際に足を当ててバックを傾ける支点とします。

■ 安全上の注意 必ずお読みください

⚠ 注意 人が傷害を負ったり物的損害の発生が想定される内容です。

- キャリーハンドルを本体に収納するときに、キャリーハンドルと本体との間に指を挟まないように収納してください。
- バッグが不用意に動く可能性のある状況(階段や電車の乗降口などの段差のあるところやエスカレーターなど)や自立しにくい状況では、横に寝かせて固定してください。
- 棚など高い場所におく場合は、落下する恐れがあります。
- 段差のある場所や階段でキャスターでの無理なご使用はお避けください。
- 内容物をあまり詰め込みすぎないでください。ジッパーが破損する恐れがあります。
- 走行によりキャスターは磨耗して減ります。減りが著しいときは交換してください。
- キャリーハンドルを伸ばして使用すると後方に長くなります。また、バッグは低い位置にあり、人の視界に入りにくく気づきにくい場合があります。駅などの人の多い場所で使用する際は周りの安全に配慮してください。
- キャスター部分に多量の砂やホコリが付着したり、糸くずなどが絡まるとキャスターの故障の原因になります。ご使用時にキャスターが正常に動くか確認してください。
- 連続走行した直後にキャスターに直接手を触れないでください。走行時の摩擦熱でやけどする恐れがあります。
- 本製品を荷物を運ぶ目的以外で使用しないでください。
- 本製品を改造しないでください。
- 本製品に腰掛けたり、乗らないでください。破損の恐れや、転倒してけがをする恐れがあります。
- キャリーハンドルの取っ手だけを持って本製品を持ち上げないでください。キャリーハンドルやバッグが破損する恐れがあります。
- 本製品を預け荷物として航空会社へ預ける場合は、キャリーハンドルを収納し、手提げバッグ用ホルダーで固定してください。

■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- 汗による汚れや泥の汚れは水で軽く洗い流した後に中性洗剤を含ませたスポンジでブラッシングをし、洗剤を洗い流してから陰干してください(ドライクリーニングはできません)。
- 長期の使用により、撥水性能(水を弾く力)が低下した場合は別売のS.R.スプレー等の撥水スプレーをご使用ください。
- ドライクリーニングや洗濯機による洗濯はしないでください。生地を傷める恐れがあります。

■ 保管方法

- 日の当たらない風通しの良い場所に保管してください。
- ガソリンやシンナーと一緒に保管しないでください。

■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

■ 仕様

#1133175

ウィーリーダッフル 80

【サイズ】 高さ80×幅42×奥行き29cm
【容量】 80L

#1133176

ウィーリーダッフル 100

【サイズ】 高さ85×幅44×奥行き32cm
【容量】 100L

許容荷重 30kg

許容荷重を超える荷物は入れないでください。

素材

本体：表地：ポリエステル®ナイロン・リップストップ
[ウレタン・コーティング]
裏地：ナイロン・リップストップ
[ウレタン・コーティング]
底面：ポリエステル®ウルトラ ナイロン・リップストップ
[ウレタン・コーティング]

※本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

株式会社 **モンベル** 本社 〒550-0013 大阪市西区新町 2-2-2

商品についてのお問い合わせはカスタマー・サービスまで

Tel. 06-6531-3544 フリーコール：☎ 0088-22-0031

<http://www.montbell.com>

User's Manual

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.

If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

Description

Lightweight travel bag with wheels. The smartly designed, original pull handle construction increases internal volume.

Components and Features



※Wheely Duffle 80L

1 Carry handle

The smartly designed, original pull handle construction increases internal volume.



2 Handbag holder

Strap to hold handbags. Attach the strap to the pull handle when not in use.



3 Lock compatible zipper(Main zipper only)

Zipper can be secured with TSA approved locks(sold separately).



4 Compression straps

Compression straps can be used to secure the bag's contents depending on varying internal volume.

5 Easy to open main zipper

The sturdy, fabric around zipper enables easy opening and quick accessing luggage contents.

6 Easy visual inspection of contents

The main compartment is lined with a bright gray fabric which contrasts with the bag contents for quick visual inspection.


7 Wheels

Extra-large wheels to stabilize big loads.
※Wheels can be replaced or fixed.

8 Kick plate

Protects the bottom of the bag and is used as a point of leverage.

Safety Warnings



- When lowering the carry handle, be careful of pinching fingers in the space between the shaft and the bag.
- Make sure to lay the bag down on the ground in situations where the bag can move or tip over, such as stairs, public transportation or escalators.
- To prevent accidents do NOT place the bag above head, such as a shelf on public transportation.
- Do NOT use the wheels on stairs or over uneven terrain.
- Do NOT overstuff the bag. Overstuffing can damage the zipper.
- The wheels will wear down over time and eventually need replacing.
- When using the bag's carry handle, be careful of those around you since the bag trailing behind you can become a tripping hazard.
- Sand, debris and fibers can clog the wheels and cause damage or prevent the wheels from functioning properly. Check that the wheels are in good working order before using the bag.
- Do NOT touch the wheels after they have been rolling. Wheels can become hot from friction and possibly cause burns.
- Do NOT use this product for any other purpose than for what it is designed.
- Do NOT change or alter this product in any way.
- Do NOT sit on or ride this product. The bag can tip over damaging the bag or causing injury.
- Do NOT use the carry handle to lift the bag. This can damage both carry handle and bag.
- When submitting your luggage to the airline, store the carry handle and attach the strap.

Care

Improper care and storage can shorten the lifespan of this product. Follow the recommendations below to extend the lifespan of your product.

- To clean stains and soiling, lightly rinse off and use a mild soap with a sponge to brush away any remaining residue. Rinse off and dry in the shade. Do NOT dry clean.
- Water repellent abilities will decrease over time. To restore water repellency, first clean any residues from the fabric surface and then apply a water repellent spray (sold separately).
- Do NOT dry clean or wash in a washing machine. This can damage the bag's fabric.

Storage

- Store in a well ventilated, cool, dry place.
- Do NOT store together with gasoline or paint thinner.

Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at its discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

Specifications

#1133175

Wheely Duffle 80

[Size] 80(H)×42(W)×29(D)cm
[Volume] 80L

#1133176

Wheely Duffle 100

[Size] 85(H)×44(W)×32(D)cm
[Volume] 100L

Maximum weight: 30kg

Do NOT fill with more than 30kg.

Material

Outer: Ballistic rip-stop nylon (urethane coating)

Lining: Rip-stop nylon (urethane coating)

Bottom: Ballistic ultra rip-stop nylon (urethane coating)

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN

www.montbell.com